




PARTS CATALOGUE

RIGGING-STEERING

RIGGING-STEERING
PARTS CATALOGUE
©2009 by Yamaha Motor Co., Ltd.
1st edition, April 2009
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

“UR” Use specified parts number.

“UN” Use as many as needed.

“AP” Alternate Parts

“LM” Locally Made (Parts need to be ordered locally)

“F#” Frame No. (Applicable machine No.)

“O/S” Over Size

3. The number of components for assembly

- Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
- The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

CONTENTS

BASE HANDLE - ALL	1
BASE HANDLE ELECTRICAL	4
FITTING KIT 1	5
FITTING KIT 2	6
STEERING FRICTION 1	7
FITTING KIT 3	8
STEERING FRICTION 2	9
FITTING KIT 4	10
STEERING FRICTION 3	11
FITTING KIT 5	12
FITTING KIT 6	13
STEERING FRICTION 4	14
FITTING KIT 7	15
STEERING FRICTION 5	16
FITTING KIT 8	17
STEERING FRICTION 6	18
STEERING FRICTION 7	19
STEERING FRICTION 8	20
STEERING FRICTION 9	21
STEERING FRICTION 10	22
STEERING FRICTION 11	23
STEERING FRICTION 12	24
STEERING FRICTION 13	25

INDEX

NUMERICAL INDEX	26
-----------------------	----

Application Model

			PART NO. / PART NAME								
			FIG.NO.								
MODEL CODE	MODEL NAME	SERIAL NO.	6X4-42101-02 HANDLE, STEERING	6X4-42102-00 FITTING KIT	6X4-42102-10 FITTING KIT	6X4-42102-21 FITTING KIT	6X4-42102-31 FITTING KIT	6X4-42102-41 FITTING KIT	6X4-42102-51 FITTING KIT	6X4-42102-61 FITTING KIT	6X4-42102-70 FITTING KIT
			FIG.1, 2	FIG.3, 5	FIG.4, 5	FIG.6, 7	FIG.8, 9	FIG.10, 12	FIG.11, 12	FIG.13, 14	FIG.15, 16
68V8	F115-2009	68V:1095514-	*	*							
6D65	F75-2009	62P:1011654-	*		*						
6D85	F90-2009	61P:1034038-	*		*						
6C15	F50-2009	6C1:1026054-	*			*					
6C55	F60-2009	6C5:1032264-	*			*					
6C25	T50-2009	6C2:1007662-	*			*					
6C65	T60-2009	6C6:1011071-	*			*					
67C8	F40-2009	67C:1043485-	*				*				
6H1B	90-2009	6H1:1041236-	*					*			
6H38	70-2009	6H3K:1012922-	*						*		
62XG	50-2009	6H5K:1026037-	*							*	
6BG1	F40(FI)-2009	6BG:1000001-	*								*
6BT1	F30(FI)-2009	6BT:1000001-	*								*

6X4 TILLER HANDLE KIT (50-90 & F40-F115)




FIG. 1 BASE HANDLE - ALL

REF. NO.	PART NO.	DESCRIPTION	601S				REMARKS
1	6X4-42101-02	HANDLE, STEERING	1				LM
2	6X4-42111-02-4D	HANDLE, STEERING	1				
3	93700-06M03	NIPPLE, GREASE	1				
4	6X4-48215-00	GRAPHIC	1				
5	6X4-42119-01	GRIP, STEERING HANDLE	1				
6	6X4-42177-00	RUBBER, HANDLE	1				
7	6X4-42137-00	INDICATOR, THROTTLE	1				
8	6X4-41291-00	BUSHING	1				
9	6X4-44139-01-94	COLLAR	1				
10	90152-05006	SCREW, COUNTERSUNK	1				
11	91490-20010	PIN. COTTER	1				
12	6X4-44177-00	WASHER	2				
13	6X4-42128-00	COLLAR, DISTANCE 1	1				
14	90501-23215	SPRING, COMPRESSION	1				
15	6X4-44188-00	WASHER	2				
16	90386-08032	BUSH	1				
17	63D-42126-00	FRICTION, STEERING HANDLE GRIP	1				
18	6X4-48154-00	KNOB, THROTTLE	1				
19	95380-06600	NUT, HEXAGON	1				
20	91490-20010	PIN. COTTER	1				
21	6X4-44100-00	SHIFT LINK ASSY	1				
22	6X4-42115-00	.SHAFT, STEERING HANDLE	1				
23	6X4-44102-00	.SHIFT ASSIST ASSY.	1				
24	6X4-47731-00	.GEAR, DRIVE	1				
25	6X4-44132-00	.BUSHING	1				
26	6X4-14137-00	.CLIP	1				
27	6X4-48261-00	.ARM, THROTTLE	1				

6X4 TILLER HANDLE KIT (50-90 & F40-F115)





FIG. 1 BASE HANDLE - ALL

REF. NO.	PART NO.	DESCRIPTION	601S				REMARKS
28	6X4-82540-00	.NEUTRAL SWITCH ASSY	1				
29	6A5-48129-10	.SCREW 3	2				
30	6X4-42821-00	.BAND, CLAMP	3				
31	97095-08040	BOLT	1				
32	92995-08600	WASHER	1				
33	97095-06030	BOLT	2				
34	92995-06600	WASHER	2				
35	6X4-48538-00	CLAMP, CABLE 1	1				
36	6X4-26367-00	PROTECTOR	1				
37	97095-06014	BOLT	1				
38	6X4-48538-10	CLAMP, CABLE 1	1				
39	6X4-26367-00	PROTECTOR	1				
40	97095-06014	BOLT	1				
41	6X4-42159-00	STAY	1				
42	6X4-44159-00-4D	HANDLE, GEAR SHIFT	1				
43	6X4-44173-00	LEVER, SHIFT CONTROL	1				
44	97780-60920	SCREW, TAPPING	2				
45	6G8-44191-00	INDICATOR, SHIFT	1				
46	90386-26MA3	BUSH	2				
47	6X4-42131-01	COVER, HANDLE STEERING	1				
48	97885-06016	SCREW, PAN HEAD	6				
49	92995-06600	WASHER	6				
50	6X4-42725-01	GROMMET	1				
51	63D-42121-22-4D	BRACKET	1				
52	90101-12014	BOLT	1				
53	92990-12200	WASHER, PLAIN	1				
54	90206-12M22	WASHER, WAVE	1				

[illegible]

This exploded view diagram illustrates the assembly of a vehicle's rear window. The components are numbered as follows:

- 1**: A cable or hose assembly connected to the rear window motor.
- 2**: A small cylindrical component, likely a bush or spacer.
- 3**: A pair of small, curved metal clips or fasteners.
- 4**: A bracket or mounting plate that secures the motor and cable assembly to the window frame.
- 5**: A coiled cable or hose, possibly for a heater or defogger.
- 6**: A small cylindrical component, similar to part 2.
- 7**: The rear window motor.
- 8**: A screw used to secure the motor to the window frame.
- 9**: A washer or spacer between the motor and the frame.
- 10**: A cylindrical component, likely a bush or spacer, located near the bottom of the window frame.
- 11**: A small metal bracket or clip.
- 12**: A screw used to secure the bottom of the window frame.
- 13**: A rectangular component, possibly a switch or control unit, mounted on the side of the window frame.



REF. NO.	PART NO.	DESCRIPTION	601S				REMARKS
1	6X4-82510-00	MAIN SWITCH ASSY	1				
2	676-82577-00	.CAP, KEY	1				
3	90464-08M07	CLAMP	1				
4	69W-82575-00	ENGINE STOP SWITCH ASSY	1				
5	682-82556-00	.LANYARD, STOP SWITCH	1				
-	-	-	-	-	-	-	-
6	689-8257Y-00	.CAP	1				
7	6X4-82563-00	TRIM & TILT SWITCH ASSY	1				
8	97880-06016	SCREW, PAN HEAD	1				
9	92990-06600	WASHER, PLATE	1				
10	6X4-83383-00	BUZZER	1				
-	-	-	-	-	-	-	-
11	6X4-83386-00	STAY, BUZZER	1				
12	97095-06014	BOLT	1				
13	6X4-81942-00	COVER	1				
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-

6X4 TILLER HANDLE FITTING KIT (F115)




FIG. 3 FITTING KIT 1

REF. NO.	PART NO.	DESCRIPTION	QTY	UNIT	REMARKS
1	6X4-42102-00	FITTING KIT	1		LM
2	68V-42725-10	GROMMET	1		
3	6X4-42121-10-4D	BRACKET	1		
4	90116-10175	BOLT, STUD	2		
5	90185-10051	NUT, SELF-LOCKING	4		
6	67G-48321-20	CABLE	1		
7	63D-48538-00	CLAMP, CABLE 1	1		
8	90468-10005	CLIP	1		
9	67G-26301-10	THROTTLE CABLE ASSY	1		
10	63D-48538-00	CLAMP, CABLE 1	1		
11	90468-10005	CLIP	1		
12	90464-09M42	CLAMP	1		
13	6X4-82586-20	EXT., WIRE HARNESS (L: 1.25M)	1		
14	90447-22007	TUBE	1		
15	6G5-83557-00	TUBE	1		
16	6X4-42735-00	PROTECTOR	1		
17	63D-24367-00	CLAMP, FUEL PIPE 2	1		
18	6X4-24364-00	STAY	1		
19	97095-06016	BOLT	2		
20	92995-06600	WASHER	2		
21	90465-13M24	CLAMP	5		
22	90465-13M30	CLAMP	1		

6X4 TILLER HANDLE FITTING KIT (F75,F90)





FIG. 4 FITTING KIT 2

REF. NO.	PART NO.	DESCRIPTION	QTY	UNIT	REMARKS
1	6X4-42102-10	FITTING KIT	1		LM
2	68V-42725-10	GROMMET	1		
3	6X4-42121-00-4D	BRACKET	1		
4	90185-10051	NUT, SELF-LOCKING	2		
5	90116-10031	BOLT, STUD	2		
6	67G-48321-20	CABLE	1		
7	63D-48538-00	CLAMP, CABLE 1	1		
8	90468-10005	CLIP	1		
9	67G-26301-10	THROTTLE CABLE ASSY	1		
10	63D-48538-00	CLAMP, CABLE 1	1		
11	90468-10005	CLIP	1		
12	90464-09M42	CLAMP	1		
13	6X4-82586-20	EXT., WIRE HARNESS (L: 1.25M)	1		
14	6X4-81860-00	SWITCH ASSY	1		
15	90447-22007	TUBE	1		
16	6K3-83557-00	TUBE	1		
17	6X4-42735-00	PROTECTOR	1		
18	63D-24367-00	CLAMP, FUEL PIPE 2	1		
19	6X4-24364-00	STAY	1		
20	97095-06016	BOLT	2		
21	92995-06600	WASHER	2		
22	90465-13M24	CLAMP	5		
23	90465-13M30	CLAMP	1		

6X4 TILLER HANDLE FITTING KIT
STEERING FRICTION (F75,F90,F115)



6011100-G630

FIG. 5 STEERING FRICTION 1

REF. NO.	PART NO.	DESCRIPTION	QTY	UNIT	REMARKS
1	67G-42508-10	STEERING FRICTION ASSY	1		
2	90119-08M74	.BOLT, WITH WASHER	2		
3	90201-08M01	.WASHER, PLATE	2		
4	67G-42541-00	.PIPE 1	1		
5	67G-42546-00	.NUT	2		
6	63D-42527-00	.PLATE, FRICTION	1		
7	67G-42541-10	.PIPE 1	1		
8	682-43318-01	.COVER	1		
9	90185-10M14	.NUT, SELF-LOCKING	1		
10	90201-10M76	.WASHER, PLATE	1		
11	6X4-42526-00	.PLATE, FRICTION	1		
12	97095-08025	.BOLT	2		
13	92995-08600	.WASHER	2		
14	90185-08057	.NUT, SELF-LOCKING	2		
15	67G-42561-00	.KNOB, STEERING LOCK	1		
16	67G-42562-00	.SHAFT, STEERING LOCK	1		
17	63D-42528-00	.PLATE, FRICTION	2		

6X4 TILLER HANDLE FITTING KIT (90)




FIG. 10 FITTING KIT 5

REF. NO.	PART NO.	DESCRIPTION	QTY				REMARKS
1	6X4-42102-41	FITTING KIT	1				LM
2	6X4-42121-00-4D	BRACKET	1				
3	90116-10031	BOLT, STUD	2				
4	6H1-48321-11	CABLE	1				
5	63D-48538-00	CLAMP, CABLE 1	1				
6	90468-10005	CLIP	1				
7	6H1-26301-01	THROTTLE CABLE ASSY	1				
8	63D-48538-00	CLAMP, CABLE 1	1				
9	90468-10005	CLIP	1				
10	90464-09M42	CLAMP	1				
11	6X4-82586-30	EXTENSION, WIRE HARNESS	1				
12	6X4-44159-10-4D	HANDLE, GEAR SHIFT	1				
13	6X4-44173-00	LEVER, SHIFT CONTROL	1				
14	97780-60920	SCREW, TAPPING	2				
15	90386-26MA3	BUSH	1				
16	97095-08040	BOLT	1				
17	92995-08600	WASHER	1				
18	90465-13M36	CLAMP	1				
19	90185-10051	NUT, SELF-LOCKING	2				

1

FITTING KIT
(Fig. 11, Ref. No. 2 to 14
Fig. 12, Ref. No. 1 to 8)

2

13

14

3

4

5

7

10

9

8

12

6

11


FWD

6011100-G690

[illegible]

This diagram shows an exploded perspective view of a mechanical assembly. The components are numbered as follows:

- 1**: A vertical rod or shaft at the top of the assembly.
- 2**: A long, angled rod or shaft connecting the top assembly to the bottom pulley.
- 3**: A pulley or wheel at the bottom of the assembly.
- 4**: A bolt or screw used to secure the pulley to a base.
- 5**: A small component, possibly a pin or a small pulley, located near the main pulley.
- 6**: A curved rod or arm at the top of the assembly.
- 7**: A washer or spacer ring.
- 8**: A nut or washer used to secure the top components.

[illegible]

FITTING KIT
(Fig. 13, Ref. No. 2 to 11)
(Fig. 14, Ref. No. 1 to 25)

1 2 3 4 5 6 7 8 9 10 11

0-G710

[illegible]

**6X4 TILLER HANDLE FITTING KIT
STEERING FRICTION (50)**




FIG. 14 STEERING FRICTION 5

REF. NO.	PART NO.	DESCRIPTION	QTY	UNIT	REMARKS
1	63D-42508-00	STEERING FRICTION ASSY	1		
2	63D-42527-00	.PLATE, FRICTION	1		
3	63D-42546-00	.NUT	2		
4	63D-42541-00	.PIPE 1	2		
5	90201-08M01	.WASHER, PLATE	2		
6	97095-08050	.BOLT	2		
7	92990-08600	.WASHER, PLATE	2		
8	63D-42526-00	.PLATE, FRICTION	1		
9	63D-42528-00	.PLATE, FRICTION	2		
10	63D-42562-00	.SHAFT, STEERING LOCK	1		
11	90185-10M01	.NUT, SELF-LOCKING	1		
12	63D-42561-00	.KNOB, STEERING LOCK	1		
13	682-43318-01	.COVER	1		
14	97095-06016	BOLT	2		
15	92995-06100	WASHER, SPRING	2		
16	63D-82361-00	CLAMP, CORD	1		
17	90161-06M00	SCREW, TAPPING	1		
18	97095-06035	BOLT	1		
19	92995-06600	WASHER	1		
20	90387-06M26	COLLAR	1		
21	90465-13M36	CLAMP	1		
22	63D-24364-10	STAY	1		
23	97095-06016	BOLT	1		
24	92995-06600	WASHER	1		
25	63D-24367-00	CLAMP, FUEL PIPE 2	1		

FITTING KIT
(Fig. 15, Ref. No. 2 to 12
Fig. 16, Ref. No. 1 to 17)

11 12 10 2 4 7 6 5 9 3 8

FWD


601S10S-H150

REF. NO.	PART NO.	DESCRIPTION	601S				REMARKS
1	6X4-42102-70	FITTING KIT	1				LM
2	90185-10051	NUT, SELF-LOCKING	2				
3	67C-48321-11	CABLE	1				
4	63D-48538-00	CLAMP, CABLE 1	1				
5	90468-10005	CLIP	1				
-	-	-	-	-	-	-	-
6	69W-26301-00	THROTTLE CABLE ASSY	1				
7	63D-48538-00	CLAMP, CABLE 1	1				
8	90468-10005	CLIP	1				
9	90464-09M42	CLAMP	1				
10	6X4-82586-10	EXT., WIRE HARNESS (L: 950MM)	1				
-	-	-	-	-	-	-	-
11	6X4-81860-00	SWITCH ASSY	1				
12	90465-13M36	CLAMP	1				
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-

This exploded perspective view illustrates the assembly of a mechanical component, likely a bracket or support arm, with various fasteners and sub-components. The parts are identified by the following callouts:

- 1**: A large, flat rectangular plate or base.
- 2**: A curved, L-shaped bracket or support arm.
- 3**: A small screw or bolt.
- 4**: A small rectangular plate or bracket.
- 5**: A small circular washer or spacer.
- 6**: A small screw or bolt.
- 7**: A small rectangular plate or bracket.
- 8**: A small rectangular block or spacer.
- 9**: A small circular washer or spacer.
- 10**: A small circular washer or spacer.
- 11**: A small circular washer or spacer.
- 12**: A small screw or bolt.
- 13**: A small screw or bolt.
- 14**: A small screw or bolt.
- 15**: A small screw or bolt.
- 16**: A small circular washer or spacer.
- 17**: A small screw or bolt.


The diagram shows the assembly sequence and relative positions of these components. For example, the bracket (2) is shown being attached to the base (1) using screws (3, 5, 6, 10, 11, 13, 17) and washers (9, 10, 11). The small plate (4) is shown being attached to the bracket (2) using a screw (12) and a washer (16). The block (8) is shown being attached to the bracket (2) using a screw (7) and a washer (9).



REF. NO.	PART NO.	DESCRIPTION	601S				REMARKS
1	67C-42508-03	STEERING FRICTION ASSY	1				
2	67C-42527-03	.PLATE, FRICTION	1				
3	90109-06M88	.BOLT	2				
4	67C-42525-00	.PLATE, FRICTION	1				
5	92990-06100	.WASHER, SPRING	2				
6	67C-42562-00	.SHAFT, STEERING LOCK	1				
7	67C-42561-00	.KNOB, STEERING LOCK	1				
8	689-43633-00	.COVER, TILT LEVER	1				
9	90202-10M56	.WASHER, PLATE	2				
10	65W-42528-00	.PLATE, FRICTION	2				
11	90209-10M26	.WASHER	1				
12	90387-05M05	.COLLAR	1				
13	90185-10M14	.NUT, SELF-LOCKING	1				
14	90387-05M11	.COLLAR	1				
15	97095-05020	.BOLT	1				
16	92995-05600	.WASHER	1				
17	95380-05600	.NUT	1				

STEERING FRICTION

Part No.	Applicable model
6AH-42508-00	F9.9F(F9.9), FT9.9G(T9.9), F13.5B, F15C (F15), F20B (F20) MT
6AH-42508-10	FT9.9G(T9.9), F13.5B, F15C (F15), F20B (F20) PT



601S10S-H170

FIG. 17 STEERING FRICTION 7

REF. NO.	PART NO.	DESCRIPTION	601S				REMARKS
1	6AH-42508-00	STEERING FRICTION ASSY	1				UR
	6AH-42508-10	STEERING FRICTION ASSY	1				UR
2	68T-42525-01	.PLATE, FRICTION	1				
3	90119-05018	.BOLT, WITH WASHER	2				
4	67C-42562-00	.SHAFT, STEERING LOCK	1				
5	90202-10M56	.WASHER, PLATE	2				
6	68T-42561-00	.KNOB, STEERING LOCK	1				
7	689-43633-00	.COVER, TILT LEVER	1				
8	65W-42528-00	.PLATE, FRICTION	2				
9	90387-05M05	.COLLAR	1				
10	90387-05M11	.COLLAR	1				
11	97095-05020	.BOLT	1				
12	92995-05600	.WASHER	1				
13	90209-10M26	.WASHER	1				
14	90185-10M14	.NUT, SELF-LOCKING	1				
15	6AH-42527-00	.PLATE, FRICTION	1				
16	90101-08022	.BOLT	2				
17	90201-08065	.WASHER, PLATE	2				
18	68T-43155-00	.MARK 1	1				FOR 6AH-42508-00

STEERING FRICTION

Part No.	Applicable model
65W-42508-00	F25A (F25), F25D (F25), E40X




FIG. 18 STEERING FRICTION 8

REF. NO.	PART NO.	DESCRIPTION	QTY	UNIT	REMARKS
1	65W-42508-00	STEERING FRICTION ASSY	1		
2	93700-06M03	.NIPPLE, GREASE	1		
3	65W-42527-00	.PLATE, FRICTION	1		
4	90109-06M88	.BOLT	2		
5	92990-06100	.WASHER, SPRING	2		
6	65W-42562-00	.SHAFT, STEERING LOCK	1		
7	65W-42561-00	.KNOB, STEERING LOCK	1		
8	689-43633-00	.COVER, TILT LEVER	1		
9	90202-10M56	.WASHER, PLATE	1		
10	65W-42528-00	.PLATE, FRICTION	2		
11	90209-10M26	.WASHER	1		
12	90185-10M14	.NUT, SELF-LOCKING	1		
13	90387-05M11	.COLLAR	1		
14	90109-05M89	.BOLT	1		

Part No.	Applicable model
67C-42508-03	F30A (F30), F30B (F30), F40B (F40), F40F(F40)



FIG. 19 STEERING FRICTION 9

REF. NO.	PART NO.	DESCRIPTION	601S				REMARKS
1	67C-42508-03	STEERING FRICTION ASSY	1				
2	67C-42527-03	.PLATE, FRICTION	1				
3	90109-06M88	.BOLT	2				
4	67C-42525-00	.PLATE, FRICTION	1				
5	92990-06100	.WASHER, SPRING	2				
6	67C-42562-00	.SHAFT, STEERING LOCK	1				
7	67C-42561-00	.KNOB, STEERING LOCK	1				
8	689-43633-00	.COVER, TILT LEVER	1				
9	90202-10M56	.WASHER, PLATE	2				
10	65W-42528-00	.PLATE, FRICTION	2				
11	90209-10M26	.WASHER	1				
12	90387-05M05	.COLLAR	1				
13	90185-10M14	.NUT, SELF-LOCKING	1				
14	90387-05M11	.COLLAR	1				
15	97095-05020	.BOLT	1				
16	92995-05600	.WASHER	1				
17	95380-05600	.NUT	1				

STEERING FRICTION

Part No.	Applicable model
63D-42508-00	FT50C, F50D, 40V, 50H (50), 40Y




FIG. 20 STEERING FRICTION 10

REF. NO.	PART NO.	DESCRIPTION	601S				REMARKS
1	63D-42508-00	STEERING FRICTION ASSY	1				
2	63D-42527-00	.PLATE, FRICTION	1				
3	63D-42546-00	.NUT	2				
4	63D-42541-00	.PIPE 1	2				
5	90201-08M01	.WASHER, PLATE	2				
6	97095-08050	.BOLT	2				
7	92990-08600	.WASHER, PLATE	2				
8	63D-42526-00	.PLATE, FRICTION	1				
9	63D-42528-00	.PLATE, FRICTION	2				
10	63D-42562-00	.SHAFT, STEERING LOCK	1				
11	90185-10M01	.NUT, SELF-LOCKING	1				
12	63D-42561-00	.KNOB, STEERING LOCK	1				
13	682-43318-01	.COVER	1				
14	97095-06016	BOLT	2				
15	92995-06100	WASHER, SPRING	2				
16	63D-82361-00	CLAMP, CORD	1				
17	90161-06M00	SCREW, TAPPING	1				
18	97095-06035	BOLT	1				
19	92995-06600	WASHER	1				
20	90387-06M26	COLLAR	1				
21	90465-13M36	CLAMP	1				
22	63D-24364-10	STAY	1				
23	97095-06016	BOLT	1				
24	92995-06600	WASHER	1				
25	63D-24367-00	CLAMP, FUEL PIPE 2	1				

Part No.	Applicable model
692-42508-01	60F, 70B (70), 75C, 90A (90)




FIG. 21 STEERING FRICTION 11

[illegible]

STEERING FRICTION

Part No.	Applicable model
67G-42508-10	F75B (F75), F80B, F90B (F90), F95A, F100D, F100B, F115A (F115), F75C, F80C



601S10S-H230

FIG. 23 STEERING FRICTION 13

REF. NO.	PART NO.	DESCRIPTION	QTY	UNIT	REMARKS
1	67G-42508-10	STEERING FRICTION ASSY	1		
2	90119-08M74	.BOLT, WITH WASHER	2		
3	90201-08M01	.WASHER, PLATE	2		
4	67G-42541-00	.PIPE 1	1		
5	67G-42546-00	.NUT	2		
6	63D-42527-00	.PLATE, FRICTION	1		
7	67G-42541-10	.PIPE 1	1		
8	682-43318-01	.COVER	1		
9	90185-10M14	.NUT, SELF-LOCKING	1		
10	90201-10M76	.WASHER, PLATE	1		
11	6X4-42526-00	.PLATE, FRICTION	1		
12	97095-08025	.BOLT	2		
13	92995-08600	.WASHER	2		
14	90185-08057	.NUT, SELF-LOCKING	2		
15	67G-42561-00	.KNOB, STEERING LOCK	1		
16	67G-42562-00	.SHAFT, STEERING LOCK	1		
17	63D-42528-00	.PLATE, FRICTION	2		

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
90386-26MA3	10 - 15	90468-10005	10 - 9	95380-05600	19 - 17						
90387-05M05	7 - 12		11 - 8		22 - 17						
	9 - 12		11 - 11	95380-06600	1 - 19						
	16 - 12		13 - 6	97080-06035	12 - 4						
	17 - 9		13 - 9		21 - 4						
	19 - 12		15 - 5	97095-05020	7 - 15						
	22 - 12		15 - 8		9 - 15						
90387-05M11	7 - 14	90501-23215	1 - 14		16 - 15						
	9 - 14	91490-20010	1 - 11		17 - 11						
	16 - 14		1 - 20		19 - 15						
	17 - 10	92990-06100	7 - 5		22 - 15						
	18 - 13		9 - 5	97095-06014	1 - 37						
	19 - 14		16 - 5		1 - 40						
	22 - 14		18 - 5		2 - 12						
90387-06M26	14 - 20		19 - 5	97095-06016	3 - 19						
	20 - 20		22 - 5		4 - 20						
90387-12M02	1 - 55	92990-06600	2 - 9		14 - 14						
90447-22007	3 - 14	92990-08600	12 - 7		14 - 23						
	4 - 15		14 - 7		20 - 14						
90464-08M07	2 - 3		20 - 7		20 - 23						
90464-09M42	3 - 12		21 - 7	97095-06030	1 - 33						
	4 - 12	92990-12200	1 - 53	97095-06035	14 - 18						
	6 - 10	92990-12600	1 - 58		20 - 18						
	8 - 10	92995-05600	7 - 16	97095-08025	5 - 12						
	10 - 10		9 - 16		23 - 12						
	11 - 12		16 - 16	97095-08040	1 - 31						
	13 - 10		17 - 12		10 - 16						
	15 - 9		19 - 16	97095-08050	14 - 6						
90465-13M24	3 - 21		22 - 16		20 - 6						
	4 - 22	92995-06100	14 - 15	97780-60920	1 - 44						
90465-13M30	3 - 22		20 - 15		10 - 14						
	4 - 23	92995-06600	1 - 34	97880-06016	2 - 8						
90465-13M36	6 - 13		1 - 49	97885-06016	1 - 48						
	8 - 12		3 - 20								
	10 - 18		4 - 21								
	11 - 14		14 - 19								
	14 - 21		14 - 24								
	15 - 12		20 - 19								
	20 - 21		20 - 24								
90468-10005	3 - 8	92995-08600	1 - 32								
	3 - 11		5 - 13								
	4 - 8		10 - 17								
	4 - 11		23 - 13								
	6 - 6	93700-06M03	1 - 3								
	6 - 9		18 - 2								
	8 - 6	95380-05600	7 - 17								
	8 - 9		9 - 17								
	10 - 6		16 - 17								